

■ Switches and connectors on the circuit board

Remove the 4 screws to detach the electrical control cover.

* Refer to "9 Installation Method for Each System Configuration" on page 109 about setting the switch.

Electrical control base

